



## CAJA / BOX

Tacón i: Acero cromado / Chromed steel

Tacón L: Acero cromado / Chromed steel

Tacón g: Metal pulido / Polished brass

## AGUJAS / HANDS

Tacón i: Acero pulido o pintadas en negro, blanco o rojo / Polished or painted in black, white or red steel

Tacón L: Madera de nogal lacada negra, blanca o roja / Black, white or red lacquered walnut wood

Tacón g: Madera de nogal o wenge / Walnut or wenge wood

## SEÑALES HORARIAS / TIME SIGNALS

Tacón i: Acero cromado / Chromed steel

Tacón L: Acero cromado / Chromed steel

Tacón g: Metal pulido / Polished brass

## MECANISMO / MECHANISM

UTS alemán / UTS German